

Description



The EDMO 15TAS Adjustable Support Stands are designed for supporting vehicles during maintenance and repairs.

Height adjustments are made by screwing the inner manually.

Specifications

Working Load Limit 1st stage: Closed height with load cap: Raised height with load cap: Maximum operating height with standard base: Estimated Weight:

Supplied with Dish Load Cap.

This is not a jack intended to lift any load.

ACCESSORIES

EDMO STC - Jack Stand Carrier

For movement of stands around the workplace and positioning them under vehicles. The Stand Carrier provides greatest manoeuvrability. The stand carrier has a hand pumped jack which raises or lowers the carriers spigot to align with the socket on the stand. When engaged the jack is pumped to lift the stand off the ground. The carrier can then be manoeuvred to carry the stand to where it is required. To lower the stand the jack is released and the stand carrier can be removed. The stand carrier has swivel wheels for manoeuvrability which can be braked to prevent rolling away.

15,000kgs

481mm

775mm

780mm

25kgs

Suitable for all EDMO Jack Stand models.

ph: +61 7 5591 2400 www.edmo.com.au



EDMO JST - Jack Stand Transporter

For the movement of stands around the workplace, and for positioning stands under vehicles from a greater distance.

The Transporter has a spigot which fits into the socket on the EDMO Jack Stand. By pushing down on the end of the handle, the stand will be picked up, enabling movement. To release the stand, the handle of the Transporter is lifted and pulled away from the stand to disengage from the spigot.

Suitable for all EDMO Jack Stand models.

Net Weight: 80kgs each

Width: 800mm Length: 3140mm Height: 750mm

EDMO JSTF - Jack Stand Transporter with Folding Handle

The EDMO JSTF has all the features and same functionality as the EDMO JST, with added handle height for further leverage. The JSTF is recommended for larger and heavier Jack Stand models, or where the Jack Stands will be manoeuvred with heavy extensions in place.

The JSTF is compatible with all EDMO Jack Stand models.

EDMO Stand Forklift Attachment

For those situations when it is easier to transport the stand via vehicle, possibly due to rough terrain or distance to travel around the workshop or site.

The fork attachment is fitted to the forklift tines and secured by a chain around the backrest.

The stand socket will then take the spigot on the fork attachment.

Working Load Limit: 1000 Kgs

Weight: 160kgs

Additional Information

PLEASE ENQUIRE TO WORK WITH OUR ENGINEERS TO CREATE CUSTOM LOAD CAPS, EXTENSIONS, ENGAGEMENTS AND ACCESSORIES TO SUIT YOUR SPECIFIC REQUIREMENTS.

LOAD CAPS AND EXTENSIONS ARE TO BE USED UNDER AN ADVISORY STANDARDS CODE OF PRACTICE, IN CONJUNCTION WITH SITE SAFE OPERATING PROCEDURES/RISK ASSESSMENT.

Packed on half pallet for Australian market and on skid for exportation. For more packing options, long distance and export requirements, please enquire.

ph: +61 7 5591 2400 www.edmo.com.au