

Description



For movement of stands around the workplace and positioning them under vehicles. The Stand Carrier provides greatest maneuverability. The stand carrier has a hand pumped jack which raises or lowers the carrier's spigot to align with the socket on the stand. When engaged the jack is pumped to lift the stand off the ground. The carrier can then be manoeuvred to carry the stand to where it is required. To lower the stand the jack is released and the stand carrier can be removed. The stand carrier has swivel wheels for manoeuvrability which can be braked to prevent rolling away.

Suitable for all stands JS2, JS5, JS10, JS15 & JS20 and 50t Kress Stand.

Additional Information

PLEASE ENQUIRE TO WORK WITH OUR ENGINEERS TO CREATE CUSTOM ACCESSORIES TO SUIT YOUR SPECIFIC REQUIREMENTS.

Packed on half pallet for Australian market and on skid for exportation. For more packing options, long distance and export requirements, please enquire.